

# E-Z PATCH<sup>®</sup> 10 F.S.

## BLUE SPLASH QUARTZ POOL PLASTER REPAIR KIT FOR UNDERWATER OR ABOVE WATER FAST SET REPAIRS

A EASY TO USE REPAIR KIT THAT LOOKS LIKE ORIGINAL QUARTZ PLASTER

**E-Z PRODUCTS**

888-439-7282

**NET WT. 50 LB. (22.7 Kg)**

**REPAIR KIT CONTAINS 50 LB. (22.25 Kg) DRY CEMENT/QUARTZ MIX  
COVERAGE: APPROX. 15 SQ FT. (3/8" DEEP)**

**UNDER WATER REPAIRS:** **1.** Remove loose cement and chip area at least 3/8" deep. Clean surface. **2.** Add water sparingly to **E-Z PATCH 10 F.S. DRY CEMENT MIX** and mix it into a very thick consistency, enough to be used within 5 min. Use warm water for even faster set and cold water to slow set. **3.** Wait a couple of minutes (until the materials start to harden), place a little more than needed in your hand or plastic bag. Install **E-Z PATCH 10 F.S.** firmly on the area. **4.** Slowly flatten smooth and flush with a trowel & clean edges. Expose the quartz lightly by troweling it. Slowly back away from repair. **Allow repair to set hard before swimming.**

**ABOVE WATER REPAIRS:** **1.** Follow steps 1. & 2. above, but add a little more water to the dry mix. **2a. FOR CRACK REPAIRS:** Crack should be saw-cut & cleaned if not min. 1/8" wide & 1/4" deep. Rub **E-Z PATCH 10 F.S.** deep into crack and remove excess with a sponge.

**2b. FOR CHIPS OR LARGER AREAS** -Firmly trowel **E-Z PATCH 10 F.S.** filling the area. Trowel again (not as firmly) flat and smooth. Remove excess from edges with a moist sponge. After patch stiffens, trowel again & lightly sponge to reveal Quartz and trowel again to finish. To reveal Quartz, you can also (the next day) wet the area with water and apply 1/3 Muratic Acid to 2/3 water, lightly scrubb and then rinse with water within 1 minute. **Allow repair to set hard before filling pool.**

**View our instructional repair video showing how to do this repair at [www.e-zpatch.com](http://www.e-zpatch.com)**

**WARNING:** CONTAINS CEMENT, AN ALKALINE SUBSTANCE IRRITATING TO EYES AND SKIN. SHOULD PRODUCT CONTACT EYES, FLUSH THEM IMMEDIATELY AND REPEATEDLY WITH WATER AND CALL A PHYSICIAN. DO NOT TAKE INTERNALLY. IN CASE OF SKIN CONTACT, RINSE IMMEDIATELY WITH WATER. USE OF RUBBER GLOVES IS RECOMMENDED.

**KEEP OUT OF THE REACH OF CHILDREN**

**MADE IN THE U.S.A.**

