

E-Z PATCH[®] 9 F.S.

BLUE/GREY PEBBLE PLASTER REPAIR KIT FOR UNDERWATER OR ABOVE WATER FAST SET REPAIRS

A EASY TO USE REPAIR KIT THAT LOOKS LIKE ORIGINAL PEBBLE PLASTER

E-Z PRODUCTS

888-439-7282

NET WT. 50 LB. (22.7 Kg)

REPAIR KIT CONTAINS 50 LB. (22.7 Kg) DRY CEMENT MIX

COVERAGE: APPROX. 15 SQ. FT. (3/8" DEEP)

E-Z INSTRUCTIONS:

UNDER WATER REPAIRS: 1. Remove loose cement and chip area at least 3/8" deep. Clean surface. 2. Add water sparingly to **E-Z PATCH 9 F.S. DRY CEMENT MIX** and mix it into a very thick consistency enough to be used within 5 min. Use warm water for even faster set and cold water to slow set. 3. Wait a couple of minutes (until the materials start to harden), place a little more than needed in your hand or plastic bag. Install **E-Z PATCH 9 F.S.** firmly on the area. 4. Slowly flatten smooth and flush with a trowel & clean edges with a sponge. Expose the pebble lightly with a sponge. To match very small "mini pebble", do not expose as much. Slowly back away from repair. **Allow repair to set hard before swimming.**

ABOVE WATER REPAIRS: 1. Follow steps 1. & 2. above, but add a little more water.

2a. FOR CRACK REPAIRS: Cut crack 3/8" wide & 3/8" deep, clean surface, rub **E-Z PATCH 9 F.S.** deep into crack and remove excess with a moist sponge. **2b. FOR CHIPS OR LARGER AREAS:** Firmly trowel **E-Z PATCH 9 F.S.** filling the area. Trowel flat and smooth. Remove excess from edges with a moist sponge. Spray with a water hose or use a wet sponge to expose the pebble. To match very small "mini pebble", do not rinse as much.

6. If there is any residue "haze" the next day, it can be removed by wetting the surface with water & pouring a mixture of 1/3 muratic acid to 2/3 water on the patched area. Wait 1 minute and rinse using a waterhose. **Allow repair to set hard before filling pool.**

View our instructional repair video showing how to do this repair at www.e-zpatch.com

WARNING: CONTAINS CEMENT, AN ALKALINE SUBSTANCE IRRITATING TO EYES AND SKIN. SHOULD PRODUCT CONTACT EYES, FLUSH THEM IMMEDIATELY AND REPEATEDLY WITH WATER AND CALL A PHYSICIAN. DO NOT TAKE INTERNALLY. IN CASE OF SKIN CONTACT, RINSE IMMEDIATELY WITH WATER. USE OF RUBBER GLOVES IS RECOMMENDED.

KEEP OUT OF THE REACH OF CHILDREN

MADE IN THE U.S.A.

