

# E-Z PATCH<sup>®</sup> 10

## BLUE SPLASH QUARTZ POOL PLASTER REPAIR KIT

A EASY TO USE REPAIR KIT THAT LOOKS LIKE ORIGINAL QUARTZ PLASTER

**E-Z PRODUCTS**

888-439-7282

**NET WT. 50 LB. (22.7 Kg)**

**REPAIR KIT CONTAINS 32 FL. OZ. (.90 liter) LIQUID CEMENT BONDER  
AND APPROX. 50 LB. (22.7 Kg) DRY CEMENT/QUARTZ MIX  
COVERAGE: APPROX. 15 SQ FT. (3/8" DEEP)**

### **E-Z INSTRUCTIONS:**

1. Lower water below repair area. 2. Remove loose cement and chip area down at least 3/8" deep. 3. Add 2 oz. of LIQUID CEMENT BONDER per 3 lb. **E-Z PATCH 10** DRY CEMENT MIX. Add water and mix until you get the consistency of "mashed potatoes". Use warm water for faster set and cold water to slow set.

**4a. FOR CRACK REPAIRS** – Crack should be saw-cut & cleaned if not min. 1/8" wide & 1/4" deep. Rub **E-Z PATCH 10** deep into crack and remove excess with a sponge.

**4b. FOR CHIPS OR LARGER AREAS** -Firmly trowel **E-Z PATCH 10** filling the area. Trowel again (not as firmly) flat and smooth. Remove excess from edges with a moist sponge. After patch stiffens, trowel again, lightly sponge to reveal Quartz and trowel again to finish. To reveal Quartz, you can also (the next day) wet the area with water and apply 1/3 Muratic Acid to 2/3 water, lightly scrubb and then rinse with water within 1 minute.

**You may refill water the next day**

**View our instructional repair video showing how to do this repair at [www.e-zpatch.com](http://www.e-zpatch.com)**

**WARNING:** CONTAINS CEMENT, AN ALKALINE SUBSTANCE IRRITATING TO EYES AND SKIN. CONTAINS ACRYLIC RESIN CEMENT BONDER. SHOULD PRODUCT CONTACT EYES, FLUSH THEM IMMEDIATELY AND REPEATEDLY WITH WATER AND CALL A PHYSICIAN. DO NOT TAKE INTERNALLY. IN CASE OF SKIN CONTACT, RINSE IMMEDIATELY WITH WATER. USE OF RUBBER GLOVES IS RECOMMENDED.

**KEEP OUT OF THE REACH OF CHILDREN**

**MADE IN THE U.S.A.**

